



Download Files from FIFISH ROV


for Windows Users

Version 1.0_2018-07-05

1. Install FTP client Tool

We recommend the FileZilla, you can download the newest version on filezilla' s website.

<https://filezilla-project.org>



The screenshot shows the FileZilla website's download section. On the left is a navigation menu with links for FAQ, Support, Contact, License, Privacy Policy, and Trademark Policy. Below these are sections for Development (Source code, Nightly builds, Translations, Version history, Changelog, Issue tracker) and News. The main content area features a heading 'Quick download links' with a red diamond icon. Below this are two buttons: 'Download FileZilla Client' for 'All platforms' and 'Download FileZilla Server' for 'Windows only'. A red box highlights the 'Quick download links' heading and the 'Download FileZilla Client' button. A red arrow points to the 'Click Here' text overlaid on the client button. Below the buttons is a note: 'Pick the client if you want to transfer files. Get the server if you want to make files available for others.'

2. PC and FIFISH Connection




2.1. Hardware connection

- Turn on the FIFISH Remote Controller (RC);
- connect the machine and RC with the tether, until the *Power Button* and *UNLOCK/LOCK* button is constantly on

2. PC and FIFISH Connection

2.2. Software connection

- Open the Wi-Fi and search the SSID name is "FIFISHRC_XXX" (the last 3 digits are the ID for each RC)
- The password is "1234567890"
- Connect your PC to the RC' s Wi-Fi



3. Configure FTP

Fill the "host" , "username" and "password" as below, please.

Host: 192.168.2.158

Username: guest

Password: fifish

Then click the "Quickconnect"

The screenshot shows the FileZilla interface with the following details:

- Window title: **guest@192.168.2.158 - FileZilla**
- Menu bar: File Edit View Transfer Server Bookmarks Help
- Toolbar: Contains icons for file operations, transfer, and search.
- Form fields: Host: 192.168.2.158, Username: guest, Password: •••••, Port:
- Buttons: **Click here** (red text), Quickconnect (button), and a dropdown arrow.
- Status messages:
 - Status: Connecting to 192.168.2.158:21...
 - Status: Connection established, waiting for welcome message...
 - Status: Insecure server, it does not support FTP over TLS.
 - Status: Server does not support non-ASCII characters.
 - Status: Logged in
 - Status: Retrieving directory listing...
 - Status: Directory listing of "/" successful

The password field contains the text **fifish** in red, and the Quickconnect button is highlighted with a red box.

4. Find the Pictures and Videos

The pictures and videos are stored by date

Remote site: /

Filename	Filesize	Filetype	Last mod...	Permis...	Owner...
..					
20180613		File fol	6/13/201...	drwxr...	0 0
20180701		File fol	7/1/2018...	drwxr...	0 0
20180703		File fol	7/3/2018...	drwxr...	0 0
20180704		File fol	7/4/2018...	drwxr...	0 0

Files store by date


5. Targeting Download Destination

You can select the downloading address in the “Local site” frame.



6. Select and Download

Select the Pictures or Videos you would like to down to your PC.



7. Downloading

You can monitor the progress of the downloading

Server/Local file	Dire...	Remote file	Size	Prio...	Status
guest@192.168...					
D:\Download\...	<<--	/20180701/14/M_2...	337,13...	Nor	Transferring
00:00:36 elapsed		00:01:42 left	<div style="width: 20.4%; height: 10px; background-color: green;"></div> 20.4%		69,080,756 bytes (2.6 MiB/s)

Queued files (1) Failed transfers Successful transfers